



# MiniBuddy PRO Platinum Wireless Voice Amplifier



## USER Manual

### Function Illustration




### Main Function Description

- Power Switch/ Volume Control**
- Power Indicator**
- MP3 mode indicator**  
When the indicator shows a blue light, the MiniBuddy is in Bluetooth or UHF mode. When the indicator shows a green light, the MiniBuddy is in the TF card or USB driver option mode.
- Previous**  
Press and hold the button for fast reverse; or a short press to go to the previous music selection.

- Play/Pause**  
In playing music mode, short Press the button to pause and press again to play
- Next**  
Press and hold the button for fast forward, short press to move to next music selection.
- Mode switch**  
After inserting a USB driver or TF card, short press " M " to switch the mode between USB / TF card / Bluetooth / UHF mode. In music mode, long press " M " for 3 seconds for single song looping and/or press " M " for 3 seconds to loop all songs.
- TF card slot**
- USB slot(reading data only)**
- 3.5mm microphone port for wired option**
- AUX slot**
- DC 5V charging slot Charging indicator**

### Wireless Headset Functions



### Charging the microphone:

**In charging status:** the indicator shows red while charging;

**Fully charged:** the red indicator goes off after charged fully.



### How to pair and use the wireless microphone

- Once the wireless microphone is turned on correctly the blue light will remain lit.
- Turn on the Voice Amplifier (speaker). Once on a short press on the **M** button for regular **UHF** mode, or a long press on the **M** button for about 3 seconds to enter **UHF** pairing mode.
- You will hear a voice prompt saying " **UHF** is waiting for connection" The blue "ON" light will begin to flash
- Press on the small Pair key or button with the wifi symbol on the wireless microphone until the Voice Amplifier (speaker) says " **UHF** is connected" meanwhile, the blue light stop flashing, then your voice will be amplified.

**Note:**  
A long press (3 seconds) on pair key button on the wireless microphone and or a long (3 seconds) press on the M button on the speaker will disconnect the wireless microphone from the speaker.

Please refer to the above steps to re-pair the wireless microphone back the Voice Amplifier (speaker)

**Note:**  
In UHF mode, a short press on the "+" or "-" buttons on the wireless microphone will turn the volume up/down.

### Operation Description

- How to amplify your voice**  
Turn on speaker with power switch on the top of control panel, if need be; pair the speaker and the wireless microphone, position the microphone in front of your mouth and speak
- How to play music via TF card/ USB driver**  
Insert a TF card or USB into corresponding slot and the speaker will play music automatically; Press for previous or next song  
  
" " to previous or next song (TF card or USB is NOT included)
- How to play music via AUX input**  
Connect speaker to external audio device with 3.5mm audio output via audio cable included


### How to connect with Bluetooth

- Click " M " to switch to Bluetooth mode, the MP3 mode indicator shows blue light, and there will a voice prompt saying "Bluetooth is waiting for connection"
- Turn on the Bluetooth transmitting device and search for the name S619 to pair.

### How to charge speaker:

Turn the speaker off and charge it when the speaker prompts with "low battery please charge".

The red indicator light is always on when charging. Once fully charged, the red indicator light will turn off




### Please note:

- Use a standard USB charger plug with the provided power cable charge the speakers internal rechargeable battery.
- Plug adapter into 110-240 AC outlet. Connect the cable end into the DC 5V power input on speaker.
- It will normally take 3-5 hours to fully charge the battery.
- When charging is required, a voice prompt will indicate, "Low battery, please charge", the battery indicator will blink while charging. It will stop blinking when battery is fully charged.
- Recharge the battery within 48 hours of "low battery" voice prompt. In order to extend the life of the internal battery, please charge it regularly even if system is not being used.
- It is suggested that you charge the internal battery an additional 1- 2 hours after fully charged to extend its life on this first charge cycle only and again if the unit has not been used for an extended period.
- Please DO NOT overcharge the battery by leaving the system plugged in continuously. This will reduce the life of the internal rechargeable battery and could cause overheating.

### Specifications:

Output power	≤ 16W	Frequency response	80Hz-18KHz
Speaker Impedance	4Ω	Working temperature	-10°C-45°C
Charging Voltage	DC 5V= 1A	Charging time	3H-5H
Music mode time	8H-8H (medium volume)	Amplify time	4H-6H(wired)



### Package includes:

- 1 \*speaker
- 1\*headset microphone
- 1\*waistband
- 1\*charging cable
- 1\*audio cable
- 1\*user manual

### After-sales support

ALDS provides one year warranty on the MiniBuddy Pro amplifier and headset microphone from date of purchase by the end user.

Accessory items come with a 60 day warranty from date of purchase by end user.

ALDS: 1.866.845.2537 sales@alds.com



## PRO PLATINUM

--	--	--	--	--